

MINI ROKIN[®] TANK 2.0

500MAH BATTERY
510 THREADED CONNECTION
12MM DIAMETER OPENING
ADAPTER FITS 10MM & 14MM FEMALE FITTINGS
4 VOLTAGE SETTINGS
POWERWAVE HEATING TECHNOLOGY (3.6v-2.2v)
15 SECOND PREHEAT FUNCTION (1.8v)
5 MINUTE AUTO SHUT OFF
MICRO USB-C FAST CHARGING
SHORT CIRCUIT PROTECTION

510 CARTRIDGE BATTERY
+ WATERPIPE ADAPTER

VAPORIZER INSTRUCTIONS:

- CLICK BUTTON RAPIDLY 5 TIMES TO TURN ON AND OFF
- CLICK BUTTON RAPIDLY 2 TIMES TO PREHEAT YOUR BATTERY
 - DEVICE WILL PULSE IN MULTICOLORS FOR 15 SECONDS AND WILL STOP WHEN DONE
 - CLICK ANY TIME TO STOP PREHEAT
- CLICK BUTTON RAPIDLY 3 TIMES TO CHANGE THE VOLTAGE
- HOLD BUTTON AND INHALE
- LIGHT WILL FLASH AND TURN OFF AFTER 5 MINUTES IDLE
- SLIDE UP COVER TO EXPOSE CARTRIDGE

VOLTAGE SETTINGS:

- CLICK BUTTON 3 TIMES TO CHANGE VOLTAGE
- LIGHTS WILL CYCLE THROUGH EACH SETTING:
GREEN: 2.2V-1.7V **BLUE: 2.7V-2.2V** **YELLOW: 3.2V-2.7V** **RED: 3.6V-3.1V**
- CLICK DURING COLOR OF DESIRED VOLTAGE TO SELECT VOLTAGE

WATERPIPE ADAPTER INSTRUCTIONS:

- REMOVE PLUG ON BOTTOM OF DEVICE AND ATTACH THE ADAPTER
- PLACE THE DEVICE INTO THE WATERPIPE
- TURN ON VAPORIZER, HOLD BUTTON AND INHALE, WATERPIPE WILL START TO FILL
- ONCE WATERPIPE IS FULL, REMOVE DEVICE AND INHALE
- CARTRIDGE MUST BE BOTTOM AIRFLOW TO USE ADAPTER PROPERLY

BATTERY POWER INDICATOR:

- WHEN PLUGGED IN, DEVICE WILL INDICATE BATTERY CHARGE
FLASH RED: 0-30% SOLID RED: 30-70% BLUE: 70-100%
- BUTTON LIGHT WILL TURN OFF WHEN FULLY CHARGED

CONTENTS:

- MINI TANK 2.0 BATTERY, 10MM & 14MM ADAPTER, LANYARD, USB-C CHARGER

